

Heating plants

HVAC System design

Marco Manzan

University of Trieste
Department of Engineering and Architecture

April 2025

◀ ◻ ▶ ◀ ◻ ▶ ◀ ≡ ▶ ◀ ≡ ▶ ≡ ≡ ≡ ≡ ≡ ≡ ≡

Marco Manzan (UNITS - DIA)

Heating plants

April 2025

1 / 1

Air conditioning systems

- ① liquid (**water or water with additives**), are suitable for controlling only the internal temperature and not the humidity; they are sized based on the sensible load, they are usually used for heating and cooling.
They can be of three different types:
 - radiators (winter use only)
 - fan coils (winter and summer use)
 - radiant panels (winter for heating and summer for cooling).
- ② direct expansion **systems** (winter and summer use and for small and medium powers).
- ③ all-air **systems**, are suitable for controlling both the temperature and the internal humidity; can be divided in turn
 - single duct
 - double duct
 - constant or variable flow rate
- ④ Mixed systems **air** and **water**
 - water part controls the temperature
 - air part controls the humidity

◀ ◻ ▶ ◀ ◻ ▶ ◀ ≡ ▶ ◀ ≡ ▶ ≡ ≡ ≡ ≡ ≡ ≡ ≡

Marco Manzan (UNITS - DIA)

Heating plants

April 2025

2 / 1

Classical use for heating, heat exchange by

- radiation about 30 %
- convection about 70 %

The thermal output depends on the difference between the average temperature of the radiator and the ambient air

$$\Phi = c(\Delta\theta_m)^n$$

c is a typical coefficient of the radiator

$n \sim 4/3$ for convection in turbulent regime

$\Delta\theta_m$ average temperature difference between the radiator and ambient air:

heat output change with temperature

The difference between the average temperature of the radiator and the air can be expressed as:

$$\Delta\theta_a = \left[\frac{(\theta_m + \theta_r)}{2} - \theta_{air} \right]$$

θ_m inlet temperature

θ_r outlet temperature

according to UNI EN 442 the heat flux is calculated in nominal conditions with $\Delta\theta_a = \Delta\theta_n$ with $\theta_{aria} = 20^\circ$:

$$\left. \begin{array}{l} \theta_m = 85^\circ \text{C} \\ \theta_r = 75^\circ \text{C} \end{array} \right\} \Rightarrow \Delta\theta_n = 60 \text{ K}$$

$$\left. \begin{array}{l} \theta_m = 75^\circ \text{C} \\ \theta_r = 65^\circ \text{C} \end{array} \right\} \Rightarrow \Delta\theta_n = 50 \text{ K}$$

heat power change with temperature

temperature different from the nominal one

$$c = \frac{\Phi_n}{(\Delta\theta_n)^n}$$

$$\Phi(\Delta\theta_a) = c(\Delta\theta_a)^n = \Phi_n \left(\frac{\Delta\theta_a}{\Delta\theta_n} \right)^n$$

Example of ta technical information sheet

exempla taken from a technical sheet by FONDITAL

TRIBECA

Standard supply	235 - 335 - 350 - 435	from 4 to 20 elements
	500 - 535 - 600	
	685 - 700 - 800 - 835	from 4 to 16 elements
	900 - 935 - 1000 - 1135	
	1200 - 1400 - 1435	from 4 to 9 elements
	1600 - 1735 - 1935	
	1800 - 2000	from 4 to 12 elements

Colours see colours table

Maximum working pressure 16 bar

Test pressure 24 bar

Alaternum treatment Supplied as standard

MEASURES EXPRESSED IN MILLIMETRES

Model	Heat output					
	ΔT 20 W/sect.	ΔT 30 W/sect.	ΔT 40 W/sect.	ΔT 50 W/sect.	ΔT 60 W/sect.	ΔT 70 W/sect.
235	9,6	16,0	23,1	30,6	38,6	46,9
335	12,5	21,1	30,5	40,5	51,1	62,3
350	13,0	21,8	31,5	41,9	52,9	64,4
435	15,2	25,6	37,1	49,4	62,5	76,1
500	16,9	28,5	41,3	55,1	69,7	85,0
535	17,8	30,1	43,6	58,2	73,6	89,8
600	19,5	32,9	47,8	63,8	80,8	98,6
685	21,6	36,6	53,3	71,2	90,2	110,2
700	22,0	37,3	54,2	72,5	91,8	112,2
800	24,5	41,6	60,6	81,1	102,8	125,8
835	25,4	43,1	62,8	84,1	106,7	130,5
900	27,0	45,9	67,0	89,7	113,9	139,3

Model	Heat output					
	ΔT 20 W/sect.	ΔT 30 W/sect.	ΔT 40 W/sect.	ΔT 50 W/sect.	ΔT 60 W/sect.	ΔT 70 W/sect.
935	27,9	47,5	69,2	92,7	117,7	144,0
1000	29,6	50,3	73,4	98,3	124,9	152,8
1135	33,0	56,2	82,0	110,0	139,8	171,2
1200	34,6	59,9	87,5	115,7	149,3	182,8
1400	39,7	67,9	99,2	133,3	169,6	207,9
1435	40,7	69,5	101,6	136,4	173,5	212,7
1600	45,1	77,1	112,6	151,2	192,3	235,6
1735	48,9	83,4	121,8	163,4	207,8	254,6
1800	50,7	86,4	126,3	169,4	215,4	263,9
1935	54,5	92,9	135,7	181,9	231,3	283,3
2000	56,4	96,1	140,2	188,1	239,0	292,7

Mass water flow

After sizing the radiator the required water flow can be computed

$$\Phi(\Delta\theta_a) = \Phi_n \cdot \left(\frac{\Delta\theta}{\Delta\theta_n} \right)^n = \dot{m} \cdot c \cdot \Delta\theta_{mr}$$

con

\dot{m} mass water flow(water or additive water).

c specific heat capacity (4,187 kJ/kgK for water)

$\Delta\theta$ inlet and outlet temperature difference $\Delta\theta_{mr} = \theta_i - \theta_r$.

water mass flow

Once computed the mass flow the piping can be sized using specified velocities which depend on:

- pressur losses
- noise
- corrosion
- air

recommended water velocity

Recommended velocity (m/s) for hot and chilled water networks

	pipes main	pipes secondary	branches to heating bodies
steel pipes	1.5 - 2.5	0.5 - 1.5	0.2 - 0.7
copper pipes	0.9 - 1.2	0.5 - 0.9	0.2 - 0.5
plastic pipes	1.5 - 2.5	0.5 - 1.5	0.2 - 0.7

Types of fluid flow

laminar flow

- regular flow
- low velocities
- low pressure drops or head loss
- reduced heat exchange

turbulent flow

- high velocities
- chaotic motion
- high pressure drops and strong heat exchange

dimensionless groups

Reynolds number

- heat exchanges and pressure drops are computed using correlations
- Re fundamental parameter for calculating flow type
- ratio between inertial forces and viscous forces
- for each geometry determines whether the motion is *laminar* or *turbulent*

$$Re = \frac{\rho \cdot u \cdot \cancel{L^2} \cdot \cancel{\mu}}{\mu \cdot \cancel{\mu} / L \cdot \cancel{L^2}} = \frac{\rho \cdot u \cdot L}{\mu}$$

u speed

ρ density

μ dynamic viscosity kg/(m s)

- laminar flow $Re < 2000$ in round ducts and pipes.
- transition $2000 \leq Re < 4000$
- turbulent $4000 \leq Re$

Steady Flow Energy Equation

relationship between pressure and velocity in a duct

$$(p_2 - p_1) + \frac{1}{2}\rho \cdot (u_2^2 - u_1^2) + g \cdot \rho \cdot (z_2 - z_1) + \Delta p_l = 0$$

u velocity

p pressure

z elevation

Δp_l pressure loss

Steady Flow Energy Equation

total pressure

$$P_t = p + \frac{1}{2} \cdot \rho \cdot u^2$$
$$P_{t,1} - P_{t,2} = \rho \cdot g \cdot (z_2 - z_1) + \Delta p_l$$

- the pressure difference between inlet and outlet depends on head losses and height difference
- the formula is valid for closed-circuit and open-circuit systems
- for closed-circuit systems the elevation head term disappears
- Δp_l takes into account the losses along the pipe and fittings discontinuities

pressure loss

Friction Factor

$$\frac{\Delta p}{L} = r = F_a \frac{1}{D} \rho \frac{v^2}{2}$$

r [Pa/m] pressure drop per unit length $\frac{\Delta p}{L}$

L length of the duct

D diameter of the duct


ρ density of the fluid

v velocity of the fluid

F_a friction factor

- pressure drops are proportional to the square of the velocity of the fluid
- depend on the flow regime, laminar or turbulent
- can be calculated with diagrams or formulas

Moody diagram



f and Re

- laminar flow f is affected mainly by the viscous force of the fluid flow is a function of Re only.

$$f = \frac{64}{Re}$$

- smooth tube $Re > 4000$ surface roughness submerged in laminar sublayer, f decreases with Re

$$f = \frac{0.316}{Re^{0.25}}$$

- with an increase of Re laminar becomes thinner than roughness. f increases
- if $Re > Rouse\ limit$ f depends on relative roughness ϵ/D only

can be obtained with Colebrook equation:

$$\frac{1}{\sqrt{F_a}} = -2 \cdot \log \left(\frac{k}{3,7 \cdot D} + \frac{2,51}{Re \sqrt{F_a}} \right)$$

where

k absolute roughness

Re Reynolds number

- implicit formulation
- difficult to be used for computing head losses
- other formulas are available in explicit form

Absolute roughness

low roughness

$$0.002 < k < 0.007 \text{ mm}$$

- copper
- plastic water pipe

medium roughness

$$0.02 < k < 0.09 \text{ mm}$$

- steel
- galvanized steel

high roughness

$$0.2 < k < 1.0 \text{ mm}$$

- scaled steel
- corroded steel
- concrete

Alternative formulas

Swamee-Jain

$$F_a = 0.25 \cdot \left[\log \left(\frac{k/D}{3.7} + \frac{5.74}{Re^{0.9}} \right) \right]^{-2}$$

Haaland

$$\frac{1}{F_a} = -1.8 \cdot \log \left[\left(\frac{k/D}{3.7} \right)^{1.11} + \frac{6.9}{Re} \right]$$

Atsui-saal

$$f^* = 0.11 \cdot \left(\frac{k}{D} + \frac{68}{Re} \right)^{0.25}$$

$$f^* > 0.018 \quad F_a = f^*$$

$$f^* < 0.018 \quad F_a = 0.85 \cdot f^* + 0.0028$$

simplified formulas

Quaderni Caleffi

practical formulas for F_a with different tube material

low roughness $2\mu m < k < 7\mu m$ (Cu, PE)

$$F_a = 0.316 Re^{-0.25}$$

medium roughness $20\mu m < k < 90\mu m$ (acciaio)


$$F_a = 0.07 Re^{-0.13} D^{-0.14}$$

high roughness $0.2mm < k < 1mm$ Colebrook equation or alternatives

Friction chart

from ASHRAE

steel pipes




Navigation icons: back, forward, search, etc.

Friction chart

from ASHRAE

copper pipes




Navigation icons: back, forward, search, etc.

Friction chart

from ASHRAE



plastic pipe



Navigation icons: back, forward, search, etc.

Friction chart

from Caleffi



Navigation icons: back, forward, search, etc.

- circuits with bends fittings valves
- resistance coefficients are introduced

Computing methods

- direct
- equivalent length
- kv factors kv and kv_{001}

direct method

pressure loss in fittings

$$z = \xi \cdot \rho \cdot \frac{u^2}{2}$$

ξ loss coefficient

















total pressure loss

$$\Delta z = L \cdot r + \left(\sum \xi \right) \cdot \rho \cdot \frac{u^2}{2}$$

typical pressure loss coefficients

quaderni caleffi

Diametro interno tubi rame, PEad, PEX		8-16 mm	18-28 mm	30-54 mm	>54 mm
Diametro esterno tubi acciaio		3/8"-1/2"	3/4"-1"	1 1/4"-2"	>2"
Tipo di resistenza localizzata	Simbolo				
Curva stretta a 90° $r/d = 1,5$		2,0	1,5	1,0	0,8
Curva normale a 90° $r/d = 2,5$		1,5	1,0	0,5	0,4
Curva larga a 90° $r/d > 3,5$		1,0	0,5	0,3	0,3
Curva stretta a U $r/d = 1,5$		2,5	2,0	1,5	1,0
Curva normale a U $r/d = 2,5$		2,0	1,5	0,8	0,5
Curva larga a U $r/d > 3,5$		1,5	0,8	0,4	0,4
Allargamento		1,0			
Restringimento		0,5			
Diramazione semplice con T a squadra		1,0			
Confluenza semplice con T a squadra		1,0			
Diramazione doppia con T a squadra		3,0			
Confluenza doppia con T a squadra		3,0			
Diramazione semplice con angolo inclinato (45°-60°)		0,5			
Confluenza semplice con angolo inclinato (45°-60°)		0,5			
Diramazione con curve d'invito		2,0			
Confluenza con curve d'invito		2,0			

Diametro interno tubi rame, PEad, PEX		8-16 mm	18-28 mm	30-54 mm	>54 mm
Diametro esterno tubi acciaio		3/8"-1/2"	3/4"-1"	1 1/4"-2"	>2"
Tipo di resistenza localizzata	Simbolo				
Valvola di intercettazione dritta		10,0	8,0	7,0	6,0
Valvola di intercettazione inclinata		5,0	4,0	3,0	3,0
Saracinesca a passaggio ridotto		1,2	1,0	0,8	0,6
Saracinesca a passaggio totale		0,2	0,2	0,1	0,1
Valvola a sfera a passaggio ridotto		1,6	1,0	0,8	0,6
Valvola a sfera a passaggio totale		0,2	0,2	0,1	0,1
Valvola a farfalla		3,5	2,0	1,5	1,0
Valvola a ritegno		3,0	2,0	1,0	1,0
Valvola per corpo scaldante tipo dritto		8,5	7,0	6,0	—
Valvola per corpo scaldante tipo a squadra		4,0	4,0	3,0	—
Detentore dritto		1,5	1,5	1,0	—
Detentore a squadra		1,0	1,0	0,5	—
Valvola a quattro vie		6,0		4,0	
Valvola a tre vie		10,0		8,0	
Passaggio attraverso un radiatore		3,0			
Passaggio attraverso una caldaia		3,0			

Navigation icons: back, forward, search, etc.

equivalent length

virtual length of pipe

$$L_{tot} = L + \sum L_E$$

L_{tot} virtual length of pipe

L real length of pipe

L_E equivalent length

total pressure losse

$$\Delta z = L_{tot} \cdot r$$

Navigation icons: back, forward, search, etc.

direct method

$$\Delta p_c = \xi \cdot \frac{1}{2} \cdot \rho \cdot u^2$$

$$\Delta p_c = r \cdot L_E$$

$$r = \xi \cdot \frac{\rho \cdot u^2}{2 \cdot D}$$

$$L_E = \frac{\xi \cdot D}{F_A}$$

pressure loss in valves

Flow coefficient K_v

$$G = K_v \sqrt{\Delta p} \quad G \text{ [m}^3\text{/h]}; \quad \Delta p \text{ [bar]}$$

for reduced flow rates and pressures $K_{v0,01}$

$$G = K_{v0,01} \sqrt{\Delta p \cdot 100} \quad G \text{ [l/h]}; \quad \Delta p \text{ [bar]}$$

K_v volumetric flow rate in m³/h obtained with $\Delta p = 1$ bar.

$K_{v0,01}$ volumetric flow rate in l/h with $\Delta p = 0,01$ bar.

pressure loss in valves

imperial units

Flow coefficient C_v

$$G = C_v \sqrt{\Delta p} \quad G \text{ [GPM]}; \quad \Delta p \text{ [psi]}$$

C_v volumetric flow rate in gpm obtained with $\Delta p = 1$ psi.

gpm gallon per minute


psi pounds square inch, 1 psi = 6894.8 Pa

pipe layout

There are several ways to connect heating terminals to the generator: for domestic plants, 3 layouts are mainly used:

- **one pipe**
- **two pipes**
- **manifold**, dual distribution manifolds (also called “modul”)

one pipe distribution



Temperature

$$\Delta\theta_{a3} = (\theta_{e3} + \theta_{u3}) / 2 - \theta_{aria}$$

$$\Delta\theta_{a2} = (\theta_{e2} + \theta_{u2}) / 2 - \theta_{aria}$$

$$\Delta\theta_{a1} = (\theta_{e1} + \theta_{u1}) / 2 - \theta_{aria}$$

$$\Delta\theta_{a3} > \Delta\theta_{a2} > \Delta\theta_{a1}$$

Navigation icons: back, forward, search, etc.

one pipe distribution

Characteristics

- low installation cost
- requires special attention in connecting radiators
- four way valves or bypass
- temperature drop computed on the whole ring
- the temperature of the radiator changes along the ring
- requires high flow rates to minimize the temperature differences

Navigation icons: back, forward, search, etc.


bypass

- il bypass allows the fluid to pass over each radiator
- two flows, one in the radiator and the other in the bypass




four way valve

- allows to regulate the flow inside the radiator.
- again two flows can be identified, one in the radiator and the other in the bypass of the valve.




from Caleffi

four way valve



Giacomini



IVAR

pipe sizing

each circuit is analyzed at once:

- 1 heat Φ_A heat exchanged along the whole ring it is the sum of the heat exchanged by each Φ_T heat emitter (radiator or fan coil).

$$\Phi_A = \sum_J \Phi_T$$

- 2 selection of $\Delta\theta_A$, temperature difference, between 10 and 15 K.
- 3 compute **mass flow rate**, G_A :

$$G_A = \frac{\Phi_A}{c \cdot \Delta\theta_A}$$

- 4 with the mass or volumetric flow rate select pipe diameters

pressure loss

once sized the pipes compute **totale loss**:

$$\Delta p_A = r_A \cdot L_A + \sum_i \Delta p_i + \sum_j \xi_j \cdot \rho \cdot \frac{v_A^2}{2}$$

Δp_A total loss of the ring

r_A pressure loss for unit length


L_A pipe length of ring

Δp_i pressure loss for each emitter

ξ_j pressure loss coefficient


v_A fluid velocity

layout with additional circuits




One pipe circuits in parallel

Design pressure distribution




One pipe circuits in parallel

Design pressure distribution



One pipe circuits in parallel

Design pressure distribution, with additional balancing valves



Sizing different rings in parallel

- pressure losses are different for each ring:
- Additional pressure loss ΔP_V for the rings with lower pressure loss

$$\Delta p_{V,i} = \Delta p_{A,max} - \Delta p_{A,i}$$

- compute the k_v or the k_{v001} of the balancing valve

$$K_{V,i} = \frac{G_i}{\sqrt{\Delta P_{V,i}}}$$

- Without valves, the fluid flow is large in the rings with lower pressure loss.

Change of flow rate with different pressures

Simple formula for computing the flow rate with different pressure losses

$$r = \frac{\Delta p}{L} = F_a \frac{1}{D} \rho \frac{u^2}{2}$$

tubi di media scabrezza

$$F_a = 0,07 Re^{-0,13} D^{-0,14} \sim u^{-0,13}$$

$$\Delta p \sim u^{1,87}$$

$$G \sim u \sim \Delta p^{\frac{1}{1,87}}$$

$$G' = G \left(\frac{\Delta p'}{\Delta p} \right)^{\left(\frac{1}{1,87} \right)}$$

considering possible fittings

$$G' = G \left(\frac{\Delta p'}{\Delta p} \right)^{0,525}$$

Two pipe systems


Direct Return

- classical distribution
- used together with other distribution systems
- layout requires balancing of flow rates
- heat emitters near the generator are subjected to higher pressures differences
- balancing valves are required

reverse return

- classical distribution
- used together with other distribution systems
- In a reverse-return system, the piping lengths for each branch circuit, including the main and branch pipes, are almost equal
- pressure difference is almost constant
- higher pipe length, cost and space problems

two pipes direct return




differential pressure

$$p_{e3} > p_{e2} > p_{e1}$$

$$p_{u3} < p_{u2} < p_{u1}$$

$$\Delta p_3 = (p_{e3} - p_{u3}) > \Delta p_2 = (p_{e2} - p_{u2}) > \Delta p_1 = (p_{e1} - p_{u1})$$

two pipes reverse return



available differential pressure

$$p_{e3} > p_{e2} > p_{e1}$$

$$p_{u3} > p_{u2} > p_{u1}$$

$$\Delta p_3 = (p_{e3} - p_{u3}) \simeq \Delta p_2 = (p_{e2} - p_{u2}) \simeq \Delta p_1 = (p_{e1} - p_{u1})$$

two pipes direct return


sizing and balancing

first terminal

- 1 compute flow rate and pipe diameter
- 2 size the terminal computing design pressure loss $\Delta p_{1,d}$

$$G_1 = \frac{\Phi_1}{c_l \cdot (\theta_{e1} - \theta_{u1})}$$

$$\Delta p_1 = r_1 \cdot L_1 + \sum_j \xi_{1,j} \cdot \frac{1}{2} \cdot \rho \cdot u_1^2$$



two pipes direct return

sizing and balancing


second terminal

- 1 compute available pressure difference
- 2 size the terminal computing the design pressure loss $\Delta p_{2,d}$
- 3 balance the system using the available pressure difference Δp
- 4 if the new flow rate is too large, add an additional pressure loss $\Delta p_{v,2}$

$$\Delta p_2 = \Delta p_1 + r_{21} \cdot L_{21} + \sum_j \xi_{21,j} \cdot \frac{1}{2} \cdot \rho \cdot u_{21}^2$$

$$G_2 = G_{d,2} \cdot \left(\frac{\Delta p_2}{\Delta p_{d,2}} \right)^{0.525}$$

$$\Delta p_{v,2} = \Delta p_2 - \Delta p_{2,d}$$



two pipe direct return

sizing and balancing

third terminal


- 1 compute flow rate as the sum of the one of the two previous terminals
- 2 size pipe diameter using the pressure loss Δp_3
- 3 size the terminal and compute the design pressure loss $\Delta p_{3,d}$
- 4 balance the flow rate using the available pressure Δp_3
- 5 add a pressure loss if the flow rate is too large $\Delta p_{v,3}$

$$G_{32} = G_1 + G_2$$

$$\Delta p_3 = \Delta p_2 + r_{32} \cdot L_{32} + \sum_j \xi_{32,j} \cdot \frac{1}{2} \cdot \rho \cdot u_{32}^2$$



$$G_3 = G_{d,3} \cdot \left(\frac{\Delta p_2}{\Delta p_{3,2}} \right)^{0.525}$$

$$\Delta p_{v,3} = \Delta p_3 - \Delta p_{3,d}$$



Navigation icons: back, forward, search, etc.

two pipes direct and reverse return




Navigation icons: back, forward, search, etc.

Caratteristiche


- used in new installations
- terminals connected in parallel
- sizing similar to the two pipes system
- requires balancing for correct function

co-planar manifold



co-planar manifold


Plant system



Cco-planar manifold

example





co-planar manifold

Sizing

fixed pipe diameter



- Pipe diameter is fixed
- each terminal must be balanced
- different flow rates and different temperature differences
- size the terminals using the mean temperature difference

sizing with predefined diameter and temperature difference

- set pipe diameter
- balance each terminal
- compute the additional pressure loss
- the pressure loss can be obtained with a different pipe diameter

Operating principle

The convertible radiator valves are equipped with an internal device (1) for pre-setting the head loss hydraulic characteristics. Specific passage cross sections (3) can be selected by means of the control nut (2), in order to generate the required resistance to the motion of the medium. Each passage cross section determines a specific Kv value for the creation of the head loss, which corresponds to a setting position on a graduated scale (4). Depending on the position in the system, the valve can be pre-set so as to obtain an immediate balancing of the hydraulic circuit, valid for both manual and thermostatic operation.




fonte Caleffi

Characteristic pressure loss diagram

Manual control

Valvole termostattabili preregolabili con manopola manuale




Posizione di preregolazione	Kvs (m³/h)					
	3/8" squadra	3/8" dritta	1/2" squadra	1/2" dritta	3/4" squadra	3/4" dritta
1	0,08	0,08	0,08	0,09	0,12	0,12
2	0,17	0,17	0,17	0,19	0,22	0,22
3	0,25	0,25	0,25	0,27	0,41	0,41
4	0,55	0,55	0,55	0,56	0,95	0,93
5	1,30	0,90	1,40	1,00	1,80	1,70

fonte Caleffi

Characteristic pressure loss diagram

Thermostatic control

Valvole termostattizzabili preregolabili con comando termostatico banda proporzionale 2K



		Kv (m³/h) (Banda proporzionale 2K)**					
		3/8" squadra	3/8" dritta	1/2" squadra	1/2" dritta	3/4" squadra	3/4" dritta
Posizione di prerogazione	1	0,08	0,08	0,09	0,09	0,12	0,12
	2	0,15	0,15	0,16	0,16	0,20	0,20
	3	0,22	0,22	0,23	0,23	0,32	0,32
	4	0,35	0,35	0,36	0,36	0,50	0,50
	5	0,50	0,50	0,55	0,55	0,72	0,72

fonte Caleffi

Navigation icons: back, forward, search, etc.

Sizing with predefined pipe diameter and temperature difference

procedure

- 1 for each circuit compute the flow rate
- 2 define pipe diameter and fluid velocity u_j
- 3 compute pressure losses, do not consider the pressure loss of valves
- 4 with preset valves, add the pressure loss with full open valve
- 5 for each circuit determine the required pressure loss
- 6 find the set position of the valve


Navigation icons: back, forward, search, etc.

Sizing with predefined pipe diameter and temperature difference

procedure

- 1 $G_j = \frac{\Phi_j}{c_w \cdot \Delta\theta_\rho}$ design flow
- 2 $u_j = \frac{G_j \cdot 4}{d_j^2 \cdot \pi}$ fluid velocity
- 3 $\Delta p_{c,j} = r_j \cdot L_j + \sum_k \frac{1}{2} \cdot \rho \cdot u_j^2$ circuit pressure loss
- 4 $\Delta p_{tot,max} = \Delta p_{c,max} + \Delta p_V$ maximum pressure loss
- 5 $\Delta p_{V,j} = \Delta p_{tot,max} - \Delta p_{c,j}$ pressure loss for each valve
- 6 $k_{V,j} = \frac{G_j}{\sqrt{\Delta p_{V,j}}}$ using a diagram $\Delta p_{V,j}$

Vertical distribution plants



Inlet temperature for heating $30 \div 45^{\circ}\text{C}$, Can be used for cooling during summer season Can be installed in:


floor for heating and cooling, the preferred solution in domestic homes.

wall heating and cooling, furniture problems

ceiling ideal solution for cooling

heated floor

- pipes embedded in concrete slab.
- pipes in plastic material must be fixed during installation
 - metal net with clips
 - on preformed insulation material



Heated floors

examples



heated floors

Manifold

