

# Air Conditioning Systems


Marco Manzan

**Università di Trieste**  
**Dipartimento di Ingegneria e Architettura**

May 2026

## All Air systems

Energy and mass space balance



### energy and mass balance

$$(\dot{m}_a)_u = (\dot{m}_a)_e$$

$$(\dot{m}_{av})_u = (\dot{m}_{av})_e + \dot{m}_v$$

$$m_a \cdot X_A = m_a \cdot X_I + \dot{m}_v$$

$$\dot{m}_a \cdot h_u = \dot{m}_a \cdot h_I + \Phi_S + \Phi_\lambda$$

# Space condition line

## slope of space condition line

$$\begin{aligned}\Phi_{tot} &= \dot{m}_a \cdot (h_A - h_I) \\ \dot{m}_v &= \dot{m}_a \cdot (x_A - x_I) \\ \frac{\Phi_{tot}}{\dot{m}_v} &= \frac{h_A - h_I}{x_A - x_I}\end{aligned}$$

## Winter


$$\Phi_S < 0; \Phi_\lambda > 0 \implies \Phi_{tot} < 0; \quad \frac{h_A - h_I}{x_A - x_I} = \frac{\Phi_{tot}}{\dot{m}_v} < 0$$

## Summer

$$\Phi_S > 0; \Phi_\lambda > 0 \implies \Phi_{tot} > 0; \quad \frac{h_A - h_I}{x_A - x_I} = \frac{\Phi_{tot}}{\dot{m}_v} > 0$$


# sensible and latent load

winter



# Sensible and latent load

summer



# Sensible and latent load

Balance

total load

$$\Phi_{tot} = \dot{m} \cdot (h_A - h_I)$$

auxiliary point

$$\theta_P = \theta_A$$

$$x_P = x_I$$

loads

$$\dot{m} \cdot (h_A - h_I) = \dot{m} \cdot (h_A - h_P) + \dot{m} \cdot (h_P - h_I)$$

$$\dot{m} \cdot (h_A - h_P) = \dot{m}_v \cdot (c_{p_v} \cdot \theta_A + r_0) \simeq \dot{m}_v \cdot r_0 = \Phi_{\lambda}$$

$$\dot{m} \cdot (h_P - h_I) = \dot{m} \cdot (c_{p_a} + x_I \cdot c_{p_v}) \cdot (\theta_P - \theta_I) = \dot{m} \cdot c_{pau} \cdot (\theta_A - \theta_I)$$

$$\dot{m} \cdot (h_P - h_I) = \Phi_{sen}$$

# Sensible Heat Ratio


SHR

The sensible heat ratio (SHR) of an air conditioning process is defined as the ratio of the absolute value of sensible heat to the absolute value of total heat


SHR

$$\begin{aligned} SHR &= \frac{\phi_s}{\phi_{tot}} \\ &= \frac{\phi_s}{\phi_s + \phi_\lambda} \end{aligned}$$

# Summer air conditioning cycle




# Summer condition




# Air handling unit (AHU)

summer condition



# Bypass Factor



## Mixing

$$BF = \frac{\dot{m}_{BP}}{\dot{m}_A}$$

$$\dot{m}_A h_P = \dot{m}_{BP} h_M + h_S (\dot{m}_A - \dot{m}_{BP})$$

$$\dot{m}_A (h_P - h_S) = \dot{m}_{BP} (h_M - h_S)$$


$$BF = \frac{(h_P - h_S)}{(h_M - h_S)} \approx \frac{(\theta_P - \theta_S)}{(\theta_M - \theta_S)}$$

$$BF = 0,67^n \quad 0 < BF < 1$$

$n$  number of coil rows


# Winter air conditioning cycle

Design condition




# Winter air conditioning scheme

Adiabatic humidification



# Air handling unit - AHU


winter condition



- 1 Heating coil
- 2 Humidifier
- 3 Heating coil
- 4 droplet eliminator
- 5 filters
- 6 recirculation


# Winter air conditioning cycle

zero latent load




# Winter air conditioning cycle

Maximum latent load




# Winter air conditioning cycle

steam humidifier



# winter working scheme

Steam humidifier



# heating coil


winter

## Characteristics

- heating coil, can be used as a cooling coil during summer season
- hot water provided by a boiler
- drives the humidity of point *I*
- it is driven by an humidity sensor in the conditioned space

# Winter air conditioning cycle

zero latent load



# Heating coil

winter - zero latent load

## Air side

$$\Phi_{pre,MAX} = \dot{m}_{AI}(h_{Q'} - h_M) = \dot{m}_{AI} \cdot c_{p,aria}(\theta_{Q'} - \theta_M)$$

$$\Phi_{pre,MAX} = \dot{m}_{AI} [c_{pa}\theta_{P'} + x_M(r_o + c_{pv}\theta_{P'}) - c_{pa}\theta_M - x_M(r_o + c_{pv}\theta_M)]$$

$$\Phi_{pre,MAX} = \dot{m}_{AI} [c_{pa}(\theta_{Q'} - \theta_M) + x_M c_{pv}(\theta_{Q'} - \theta_M)]$$

$$\Phi_{pre,MAX} = \dot{m}_{AI} [c_{pau}(\theta_{Q'} - \theta_M)]$$

# Cooling coil

Maximum latent load

## coil heat balance

$$|\Phi_{fr}^-| = \dot{m}_{AI}(h_M - h_P) - \dot{m}_L \cdot h_L$$

$$\dot{m}_L h_L \approx 0 \rightarrow |\Phi_{fr}^-| = \dot{m}_{AI}(h_M - h_P)$$

## Coil selection

$$BF = \frac{(h_P - h_S)}{(h_M - h_S)}$$

$$(h_M - h_P) = (h_M - h_S) + (h_S - h_P)$$

$$(h_M - h_P) = (h_M - h_S)(1 - BF)$$

**BF** BPF is selected to obtain  $X_p = X_l$

## Water side


$$\Delta\theta_{H_2O} = |\theta_m - \theta_r| = 5 \text{ K}, \theta_m = 7^\circ \text{C}, \theta_r = 12^\circ \text{C}$$

$$|\Phi_{fr}^-| = \dot{m}_{H_2O} \cdot c_{H_2O} \cdot \Delta\theta_{H_2O}$$

$$\dot{m}_{H_2O} = \frac{|\Phi_{fr}^-|}{c_{H_2O} \cdot \Delta\theta_{H_2O}}$$

# Winter air conditioning cycle

Maximum latent load



## heating coil

summer and winter condition

### Winter, maximum latent load

$$\Phi_{post,max} = \dot{m}_{AI}(h_I - h_P) = \dot{m}_{AI} \cdot c_{pau}(\theta_I - \theta_P)$$

### Water side

$$\theta_m = 70^\circ C, \Delta\theta_{H_2O} = (\theta_m - \theta_r) \approx 10 K$$

$$\dot{m}_{H_2O} = \frac{\Phi_{post,MAX}}{c_{H_2O} \cdot \Delta\theta_{H_2O}}$$

# Flow rate

## Limits

- 1 **outdoor air requirement** for acceptable air quality for occupants, depends on the number of people and activity.
- 2 **air inlet condition**  $\theta_I$
- 3 **dilute the concentration of the air contaminants**
- 4 **provide a desirable air velocity** to avoid air stratification:

## minimum outdoor air

$$\dot{m}_{AI} \geq \dot{m}_{ext,min}$$

# Flow rate

## air inlet temperature

$$\Phi_{sen} = \dot{m}_{AI} \cdot c_{pau} \cdot (\theta_A - \theta_I)$$

$$\dot{m}_{AI} = \frac{|\Phi_{sen}|}{c_{pau} \cdot \Delta\theta}$$

$$\Delta\theta \leq 20 \text{ K } \textit{inverno}$$

$$\Delta\theta \leq 10 \text{ K } \textit{estate}$$

$$\dot{m}_{AI} \geq \max\{\dot{m}_{AI,inverno}, \dot{m}_{AI,estate}\}$$


## to avoid stratification

$$n_{lavaggio} \geq 3 \text{ volumi/ora}$$

$$\dot{m}_{AI} \geq 0,34 \cdot 3 \cdot V_{locale}$$

# Multizone system


summer condition



- 1 Cooling coil
- 2 Humidifier (disabled)
- 3 Heating coil
- 4 droplet eliminator
- 5 filters
- 6 recirculation

# Multizone system

Winter condition



- 1 Heating coil
- 2 Humidifier
- 3 heating coil
- 4 droplet eliminator
- 5 filters
- 6 recirculation

# Multizone system

## Characteristics

- inlet temperature is controlled
- can deal with variable sensible loads
- can be applied with uniform latent loads
- must guarantee the external air for the most demanding zone

## latent load effect

$\varphi_j$  increases if  $\Phi_{\lambda,j} > \Phi_{\lambda,medio}$

$\varphi_j$  decreases if  $\Phi_{\lambda,j} < \Phi_{\lambda,medio}$

# Multizone system

## external air

### air flow rate required

$$\dot{m}_{AI,j} \geq \max\{\dot{m}_{rinn,min,j}, \dot{m}_{AI,inverno,j}, \dot{m}_{AI,estate,j}, \dot{m}_{lavaggio,j}\}$$

$$\dot{m}_{AI} = \sum \dot{m}_{AI,j}$$

### external air flow rate required

$$R_j = \frac{\dot{m}_{rinn,min,j}}{\dot{m}_{AI,j}}$$


$$R_{j,max} = R_{j,tot} = \frac{\dot{m}_{rinn,tot}}{\dot{m}_{AI}}$$

$$\dot{m}_{rinn,tot} = R_{j,max} \dot{m}_{AI}$$


there is an increase in energy consumption because the external air will be greater than the minimum necessary in

# Multizone system

dual-ducts system



# VAV Systems



- Air flow changes with the load
- if the load is reduced first the air flow is reduced
- possible use of variable speed ventilators or using volume dampers
- air flow is reduced up to 40
- a limit value of air flow is required for the correct air distribution
- when the load decreases the control is obtained with the hot coil
- in winter conditions the minimum air flow can be used